

## Objectives

Fix a typo.

### 38.4.1 Placing assertion system callbacks

CHANGE

— **cbAssertionSysOn**. The assertion system has become active and starts processing assertion attempts. This always occur after **cbAssertionSysInitialized**. By default, the assertion system is “started” on simulation startup, but the user can delay this by using assertion system control actions.

TO

— **cbAssertionSysOn**. The assertion system has become active and starts processing assertion attempts. This always occurs after **cbAssertionSysInitialized**. By default, the assertion system is “started” on simulation startup, but the user can delay this by using assertion system control actions.